



QuickDock Mounting with Drop-In Base

1. Install Base From Above The Sink
2. Install Faucet
3. Connect Waterlines
4. Remove Aerator and Flush Faucet

